# **DOCKET OFFICE COPY**

OUTLINE OF AN OBJECTIVE METHOD FOR SETTING ASSIGNED PROTECTION FACTORS

Robin M. Howie

Institute of Occupational Medicine Ltd. Edinburgh, Scotland

RESPIRATOR SELECTION

2

4

select a respirator to protect yourself against a substance present at 50 x TLV

3 SUBSTANCES

Sodium Hydroxide

Xylene

Crocidolite Asbestos

TOXICITY DATA

Substance	Health effect	TLV
Sodium Hydroxide	irritant,	2mgm-3
Xylene	<pre>irritant, narcotic, <cell count<="" pre=""></cell></pre>	100ppm
Crocidolite Asbestos	fibrogenic, carcinogenic	0.2fm1 <sup>-1</sup>

7

Substance	Health effect	TLV	IDLH
Sodium Hydroxide	irritant,	2mgm-3	125 x TLV
Xylene	<pre>irritant, narcotic, <cell count<="" pre=""></cell></pre>	100ppm	10 x TLV
Crocidolite Asbestos	fibrogenic, carcinogenic	0.2fm1 <sup>-1</sup>	Ca

## CONSEQUENCES OF EQUIPMENT FAILURE

the greater the consequences of failure, the greater the confidence required that adequate protection will be reliably provided

# CONSEQUENCES OF EQUIPMENT FAILURE

for a given device, or class of devices: the greater the risk, the lower the APF

# 8 CONSEQUENCES OF EQUIPMENT FAILURE

for a given device, or class of devices:

lower APF should be set for high toxicity

substances than for low toxicity substances

X

#### APF v TOXICITY

for a given device, or class of devices

Toxicity	APF
"low"	"high"
"medium"	"medium"
"high" or acute	"low"

×

if toxicity classification not known, assume "high" and set "low" APF

 $b^{11}$ 

#### CONSEQUENCES OF EQUIPMENT FAILURE

the consequences of equipment failure in high concentrations are likely to be more severe than failure in low concentrations

×

#### APF v TOXICITY & CONCENTRATION

Toxicity	APF Concentration <idlh>IDLH</idlh>	
"low"	"high"	"high-medium"
"medium"	"medium"	"medium-low"
"high" or acute	"low"	"1ow-"

#### WARNING PROPERTIES OF CONTAMINANT

if a contaminant has "good" warning properties
the wearer may be aware that less protection
is being afforded than expected

#### 14

#### WARNING PROPERTIES OF CONTAMINANT

for a given device, lower APF should be set for substances with "poor" warning properties than for substances with "good" warning properties



#### APF v WARNING PROPERTIES

		****
Contaminant Warning Property	Subjective Detection Level	APF
"poor"/nil	>TLV	"1ow"
"moderate"	cTLV	"medium"
"good"	<tlv 10<="" td=""><td>"high"</td></tlv>	"high"

# ×

#### CONTAMINANT WARNING PROPERTIES

if warning property not known, set "low" APF

#### DURATION OF WEAR

for tight fitting devices it is likely that
wearers may reduce the quality of fit to
reduce discomfort if worn for long periods

19

RMH SLIDE

20

CAROL SLIDE

21

#### DURATION OF WEAR

for a given device, consequences of failure over longer periods are likely to be more severe than failure over shorter periods

22

#### DURATION OF WEAR

for tight fitting devices, lower APF should thus be set for longer wear periods than for shorter wear periods

QUALITY OF TRAINING AND SUPERVISION

well trained and well supervised wearers

are likely to achieve better protection

from a given device than will poorly

trained and poorly supervised wearers

#### 24 FILTERING FACEPIECE

#### 25 FULL MASK + CLOTHING

26 <u>BA</u>

#### 27 QUALITY OF TRAINING AND SUPERVISION

unless the employer can demonstrate good
training and good supervision, lower APF should
be permitted to be assumed than for those
with good training and good supervision

# 28 AND SUPERVISION

an employer should be deemed to provide good training and supervision only if demonstrated that his workers achieve the expected protection

#### 29 AVAILABILITY OF WPF DATA

devices unproven in the field should be set lower APF than those of proven performance

#### SETTING APF

Standards bodies should assign Standard Protection Factors to different classes of devices.

Users should set APF for their own workplaces taking due account of the relevant factors

¥ <sup>31</sup>

#### SETTING APF

 $APF = APF-1 \times APF-2 \times APF-3$ 

where:

APF-1 f(toxicity, concentration, warning property)

APF-2 f(duration of wear)

APF-3 f(training, supervision)

32

#### SETTING APF IN THE WORKPLACE

APF-1: toxicity, concentration, warning properties

	Toxicity				
Subjective	"low"	"medium"	"high"/acute		
Detection Level	Concentration	Concentration	Concentration		
	<idlh>IDLH</idlh>	<idlh>IDLH</idlh>	<idlh>IDLH</idlh>		
<tlv 10<="" td=""><td></td><td></td><td></td></tlv>					
c TLV					
>TLV					

APF-1: toxicity, concentration, warning properties

Subjective	"low"		Toxicity "medium"		"high"/acute	
Detection Level	Concen	tration	Concen	tration	Concen	tration
<tlv 10<br="">cTLV &gt;TLV</tlv>	SPF	SPF/2	SPF/2	SPF/4	SPF/4	SPF/8

# SETTING APF IN THE WORKPLACE

APF-1: toxicity, concentration, warning properties

Subjective	<b>"</b> 10	w"	Toxi "med	city ium"	"high"	/acute
Detection Level	Concen	tration >IDLH	Concen	tration	Concen	tration
<tlv 10<="" td=""><td>SPF</td><td>SPF/2</td><td>SPF/2</td><td>SPF/4</td><td>SPF/4</td><td>SPF/8</td></tlv>	SPF	SPF/2	SPF/2	SPF/4	SPF/4	SPF/8
cTLV	SPF/2	SPF/4	SPF/4	SPF/8	SPF/8	SPF/16
>TLV	SPF/2	SPF/4				

## SETTING APF IN THE WORKPLACE

APF-1: toxicity, concentration, warning properties

Subjective	"10	"low"		Toxicity "medium" "high"/acut		
Detection   Level	Concen	tration	Concen	tration >IDLH	Concen	tration
<tlv 10<="" td=""><td>SPF</td><td>SPF/2</td><td>SPF/2</td><td>SPF/4</td><td>SPF/4</td><td>SPF/8</td></tlv>	SPF	SPF/2	SPF/2	SPF/4	SPF/4	SPF/8
c TLV	SPF/2	SPF/4	SPF/4	SPF/8	SPF/8	SPF/16
>TLV	SPF/2	SPF/4	SPF/8	SPF/16	SPF/16	SPF/32

#### SETTING APF IN THE WORKPLACE

APF-1: toxicity, concentration, warning properties

	Tox	icity - Co	oncentrati	on
Subjective Detection Level	"low" <idlh< td=""><td>"medium" <idlh or</idlh </td><td>"high" <idlh or</idlh </td><td>-</td></idlh<>	"medium" <idlh or</idlh 	"high" <idlh or</idlh 	-
	-	"low" >IDLH	"medium" >IDLH	"high" >IDLH
<tlv 10<="" td=""><td>SPF</td><td>SPF/2</td><td>SPF/4</td><td>SPF/8</td></tlv>	SPF	SPF/2	SPF/4	SPF/8
cTLV	SPF/2	SPF/4	SPF/8	SPF/16
>TLV	SPF/2	SPF/8	SPF/16	SPF/32

# SETTING APF IN THE WORKPLACE

APF-2 -3: duration of wear, training, supervision

APF-2	APF-3
Duration of wear	Training and Supervision Proven good Unproven
x 4 x 1 x ½	x 2 BM x 1 to WPF*

<u>A 1</u>

A 2

38

# DETERMINING TOXICITY CLASSIFICATION

Toxicity	Examples
"low"	mild irritants, nuisance particulates, simple asphyxiants IDLH >100 x TLV
"medium"	irritants, narcotics, weak chemical asphyxiants, fibrogenics IDLH <100 x TLV
"high" or acute	occupational carcinogens moderate + chemical asphyxiants sensitisers, allergenics, acutely troxic substances

# WARNING PROPERTIES

Substance	Warning Property	Subjective Detection Level
Sodium Hydroxide	Irritation	TLV/2
Xylene	Smell	<tlv 5<="" td=""></tlv>
Crocidolite	None*	n/a

A 3

40

# SETTING APF IN THE WORKPLACE

APF-2 -3: duration of wear, training, supervision

APF-2	APF-3		
Duration of wear	Training and Supervision		
<30min 30-60min >60min	Proven good Unproven		
x 4 x 1 x ½	x 2 BM x 1 to WPF*		

41

BLANK

A 5

# A1 EXAMPLES OF APPLICATION OF OUTLINE TECHNIQUE

Select a respirator for use against sodium hydroxide or xylene or crocidolite at 50 x TLV.

Assume no WPF or biological monitoring data available. Assume a wear period of 2hr.

A 2

	NaOH	XYLENE	CROCIDOLITE
Ambient conc'n	$100 \mathrm{mgm}^{-3}$	5,000ppm	$10  \mathrm{fm}  1^{-1}$
TLV:	2mgm-3	100ppm	0.2fm1 <sup>-1</sup>
Toxicity:	"low"	"medium"	"high"
IDLH:	200mgm <sup>-3</sup>	1,000ppm	Ca
Concentration:	<idlh< td=""><td>&gt;IDLH</td><td>&gt;IDLH</td></idlh<>	>IDLH	>IDLH
Det'n Level:	cTLV	cTLV	>TLV
APF-1:	SPF/2	SPF/8	SPF/32

#### FROM APF-2, APF-3 TABLES

A3

duration of wear - 2hr

APF-2:  $x \frac{1}{2}$ 

training & supervision - unproven

APF-3: x 1

A4 ASSIGNED PROTECTION FACTOR

 $(APF = APF-1 \times APF-2 \times APF-3)$ 

Sodium Hydroxide

 $SPF/2 \times \frac{1}{2} \times 1 = SPF/4$ 

<u>Xylene</u>

 $SPF/8 \times \frac{1}{2} \times 1 = SPF/16$ 

Crocidolite

 $SPF/32 \times \frac{1}{2} \times 1 = SPF/64$ 

A5 REQUIRED STANDARD PROTECTION FACTOR

(for substances present at 50 x TLV)

Sodium  $SPF = 200 \quad (50=SPF/4)$ 

Hydroxide

Xylene SPF = 800 (50=SPF/16)

Crocidolite SPF = 3,200 (50=SPF/64)